

Mounting the holder

1. Loosen the nuts on the risers. 2.
2. place the metal holder on the 2 threaded pins and fix it again with the nuts (Abb.1)
Tightening torque: 40-53 Nm
3. Now you can fix the headlight mask with the supplied screws (4 x DIN918C- St3,9x13).



Abb.2 montierte Scheinwerfermaske

We recommend using a medium-strength threadlocker (e.g. LOCTITE 243, blue) for the nut.