

Fitting the bow spoiler

1. Loosen the screws of the voltage transformer and take it down. (Abb.1)
2. place the lower holder between the voltage transformer and the mounting and screw it tight. these tightly (Abb.2)



Abb.1



Abb. 2

3. unscrew the horn incl. original bracket - this will be replaced by the bracket supplied by Cult-Werk. (Abb.3 & 4)



Abb. 3



Abb. 4

4. now you can place the Cult-Werk front spoiler including the upper bracket from the front of the motorbike.
Fix it together with the holder for the horn with the supplied screw (M8x20) - leave it loose. (Abb.5)
5. now screw the bow spoiler to the lower bracket.
6. align the bow spoiler as desired - then tighten all screws.



Abb. 5

We recommend using a medium-strength screw lock (e.g. LOCTITE 243, blue) for all screws.